

## USER INSTRUCTIONS

# MODIFICATION OF 12V WIRING HARNESS (LFDLHDS) TO SUIT APPLICATIONS THAT DO NOT REQUIRE HIGH BEAM SWITCHING.



Light FORCE®


**NOTE:** CHECK WITH LOCAL AUTHORITIES TO ENSURE INSTALLATION COMPLIANCE.



**INSTALLATION STEPS**

- 1. Shorten the long red trigger wire (Item D in Figure 1) and connect to red wire (Item C in Figure 1). This will allow the lights to function without the need for the “high beam” lights being active.

**Fig 1. Driving Light Harness**





**For warranty information and to register your product for warranty purposes, visit [lightforce.com/warranty](https://lightforce.com/warranty)**

**LIGHTFORCE PERFORMANCE LIGHTING INC.**

336 Hazen Lane, Orofino ID 83544 USA

[www.lightforce.com](https://www.lightforce.com) • Email: [sales@lightforce.com](mailto:sales@lightforce.com)

International Telephone: +61 8 8440 0888 | Fax: +61 8 8346 0504

All logos and images are subject to relevant trademark and copyright protection. Copyright © Lightforce Australia Pty Ltd 2019. Data and specifications may be subject to change without notice. Lightforce Australia Pty Ltd shall not be liable for damage, malfunction, failure resulting from accident, misuse, misapplication, unauthorised repair, neglect, modification, unauthorised or non standard replacement parts, accessories, bulbs, batteries or voltage or operation of the product beyond its technical and or environmental specification.